




Sun-Tek Manufacturing, Inc.
 10303 General Drive
 Orlando, FL 32824
 407 / 859-2117
 www.Sun-Tek.com
 CustomerService@Sun-Tek.com

INSTALLATION INSTRUCTIONS (LS) LABOR SAVER CURB

(Not for use on metal roofs)



SIZE INFORMATION			Fastener Schedule (#8x1" Phillips Pan Head Zinc Plated)		
Roof Opening	Glass Size Code	Poly Size Code	Fasteners Per		
			Top	Bottom	Side
11½"x27½"	1430		2	2	3
11½"x43½"	1446		2	2	4
14½"x14½"		1414	3	2	3
14½"x22½"		1422	3	2	3
14½"x30½"	1733	1430	3	2	3
14½"x46½"	1749	1446	3	2	4
19½"x19½"	2222	1919	3	2	3
19½"x27½"	2230		3	2	3
19½"x43½"	2246		3	2	4
19½"x66½"	2269		3	2	4
22½"x22½"	2525	2222	3	2	3
22½"x30½"	2533	2230	3	2	3
22½"x36½"		2236	3	2	3
22½"x46½"	2549	2246	3	2	4
22½"x69½"	2572	2269	3	2	6
27½"x27½"	3030		3	2	3
27½"x43½"	3046		3	2	4
27½"x66½"	3069		3	2	4
30½"x30½"	3333	3030	3	2	3
30½"x46½"	3349	3046	3	2	4
30½"x69½"		3069	3	2	6
36½"x36½"		3636	3	2	4
43½"x43½"	4646		3	2	4
43½"x66½"	4669		3	2	4
46½"x46½"	4949	4646	3	2	4
46½"x69½"	4972	4669	3	2	6
46½"x89½"		4689	3	2	8

You will need:

- hammer
- keyhole saw
- skill saw
- nails
- drill
- 2 x 4's

For Light Tunnel:

- 8 or 10 penny nails
- plywood or drywall

- sealant/mastic
- tape measure
- chalkline or straight edge
- trowel or caulk gun
- utility knife



RECOMMENDED SEALANTS:

- 100% Silicone
- Sealants approved for use on polycarbonate (contact Sun-Tek)
- STS 1000 (Sun-Tek exclusive) Butyl rubber sealant/caulk

FAILURE TO FOLLOW RECOMMENDED INSTALLATION PROCEDURES MAY VOID WARRANTY

Please read instructions completely before beginning. Deck and roofing felt should already be installed.

- 1 Inspect the LS for damage before installing. If the LS is damaged, do not install. Please contact your supplier for information on a replacement. Minor bends in the flange can be straitened.
- 2 To properly position the LS between trusses/rafters, locate the roof opening from the underside of the decking. Drill holes or drive nails to mark corners. (If this area is not accessible, locate the ceiling joists from inside the house, mark and cut opening in ceiling, then mark roof opening.)
- 3 Remove shingles 6 - 8" out from roof opening. Before cutting roof opening, check measurements against size chart. Snap a chalkline from corner to corner, or draw line with a straightedge, then cut roof opening.
- 4 Frame roof opening using 2 x 4's as headers - cut two 2 x 4's to fit the actual distance between trusses/ rafters and nail into place.
 - a) If applicable, cut ceiling opening and build tunnel framing. See "Light Tunnel Installation Instructions."
- 5 Shingle up roof to bottom of roof opening.
- 6 Apply a ½" wide bead of caulking, set back 1" from the roof opening around the entire opening. Set a second ½" wide bead around the entire opening, set 1" back from the first bead. Sealant applied too close to the opening may "ooze" into the opening. Can also use 3" wide x ⅛" thick butyl tape, if compatible, set ½" back from opening.



All installation information is supplied in good faith, but without recommendation to its use. No guarantee of the results of any use of this information is to be implied, since conditions of use are beyond our control. Please consult local building codes for compliance before installing.




7 Set LS over opening. Screw into place through the pre-drilled holes in the flange with the #8 x 1" phillips pan head screws provided (See *Fastener Schedule*). Cover the head of each screw with sealant.

8 Now shingle up sides and across top. Place shingles, as far in as possible, but be careful not to nail through skylight flange.

9 Bottom flange will still be exposed: we recommend leaving it this way. If you decide to put a "false shingle" over it, be careful not to nail through LS flange.

10 Interior Finishing:
Run drywall (or other finishing material) up the inside face of the skylight curb. Slip the drywall up until it bumps against the ledge in the top of the curb.


IMPORTANT:
Bottom flange of LS curb **MUST** go on top of shingles.



LIGHT TUNNEL INSTALLATION INSTRUCTIONS

For homes with an attic, it is necessary to build a tunnel between skylights and ceiling. The tunnel walls may be straight, or flared for extra light and architectural appeal. It's very easy to increase the tunnel size along the length of the ceiling joists. As long as no roof-supporting members are cut, no special framing is needed. While it is possible to flare the tunnel in all directions, if support members are cut, special framing will be required for structural support. In this case you must consult a qualified building professional to insure proper and safe results.

- 1 After roof and ceiling openings have been framed, measure distance (at each corner of roof opening) between rafter/truss and ceiling joist.
- 2 Using these four measurements, cut 2 x 4 lumber for vertical support members (two per corner).
- 3 In each corner, nail vertical support members into place at right angles to each other.
- 4 Measure, cut, and nail tunnel walls into place. Suggestions for lining tunnel:
 - use drywall, tape corners, and paint white using regular or texture paint. (Texture paint alone will hide and fill untaped joints, but in time, cracks may appear in corners.)
 - use prefinished paneling with molding in corners.
 - line the tunnel with cedar, pine, or a wood to coordinate with your decor.
 - for special effects, try painting the tunnel a striking accent color, or use mirrors or wallpaper on tunnel walls.
- 5 Caulk the slight gap between the tunnel walls and skylight base.
- 6 Finish off tunnel at ceiling with molding, or blend edges into ceiling with texture paint.
- 7 Be sure to wrap the exterior of the tunnel with insulation for energy savings.



LIMITED WARRANTY

Sun-Tek Manufacturing, Inc. ("Sun Tek") 10303 General Drive, Orlando, Florida 32824, (407) 859-2117, warrants this unit on the following terms and conditions: **A. Warranty Coverage:** This warranty applies to both the original purchaser and first consumer-owner of a unit made by Sun-Tek. **B. Warranty Duration:** This warranty shall remain in effect for a period of five (5) years after the date the unit is purchased or the date the unit is delivered to the first consumer-owner, whichever is later. One (1) year on electric components.

C. Warranty Application: This warranty applies only to the materials and fabrication of the unit and does not apply to any defect or damage caused by improper use, improper installation, improper care, shipping damage or accident. This warranty does not cover any cosmetic changes in the unit, including but not limited to pitting, hazing, paint finish, discoloration. Condensation or damaged caused by condensation is not covered under this warranty. **D. Performance by Sun-Tek:** During the warranty period, Sun-Tek will provide free of charge an equivalent new unit (or component thereof) for one found to be defective in material or workmanship. Shipping costs of such replacements are not the responsibility of Sun-Tek. Sun-Tek will not be responsible for any costs of removal or re-installation. **E. Validation Procedure:** To obtain performance under this warranty, the purchaser must: (1) On installed units, contact Sun-Tek for instructions before removing unit. Removal of the unit from roof before inspection will void warranty. (2) Notify Sun-Tek in writing of any claim within thirty (30) days after the defect is discovered; (3) Sun-Tek or its authorized agents must examine high quality installed photographs of the subject unit and determine to its satisfaction whether the defect is covered by this warranty; and (4) Present a copy of the receipt as proof of purchase. **F. Implied Warranties:** IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL NOT EXTEND BEYOND THE DURATION OF THE EXPRESS WARRANTIES PROVIDED HEREIN. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. **G. Incidental or Consequential Damages:** SUN-TEK SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES WHATSOEVER, INCLUDING BUT NOT LIMITED TO LOSS OF TIME OR REVENUE, DAMAGE RESULTING TO OTHER PROPERTY OR OTHER EXPENSES. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. **H. Exclusive Warranty:** THIS WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES. This warranty gives you specific legal rights. You may have other rights which vary from state to state.