



In the attic:

Drill a 13/32" diameter hole through tube wall, approximately 10" -16" above ceiling joist and parallel with the joist.

Build frame as shown in drawing.

Mount electrical box on centerline of hole in tube. Drill 13/32" hole through 2"x 4" framing.

Inside Your Room:

Insert the light kit assembly through the wall of the tube from the inside of the tube.

Use at maximum a 50W bulb; replace interior dome.

Push through frame and electrical box mounted on frame. secure with nuts and washers provided

Black wire is connected to the hot lead, white wire is connected to the neutral, and green wire to the ground - all wiring and connections must meet electrical code in your area.